



HPRT

Quick Start Guide



LPQ58



LPQ80

Xiamen Hanin Electronic Technology Co.,Ltd

ADD: 5F,8#,Aide Airport Industrial Park,Huli District, Xiamen, China 361009
TEL: +86-(0)592-5885993
FAX: +86-(0)592-5885992

Standard Accessories



Printer



Power Adapter



Power Cord



Cables Fastener



Quick Start Guide



CD

Note:Power adapter and power cord varies by local or region

Optional Accessories



USB Cable




Serial Cable




Paper Roll

Appearance and Components


Front




Rear



Inside




Install the Cables Fastener




## Loading Paper

1. Pull the cover open lever towards you and lift the cover.




2. Firstly, pull up the paper roll shaft. Then adjust the shaft according to the internal diameter of paper roll (There is detailed illustration which is about internal diameter of paper roll on the shaft). Next, install the paper roll and fix the shaft.




**Gap Sensor Note:** Please do center the sensor while not printing with black mark paper.


3. Pull out some paper roll, open the paper guides to the max width and pass the paper through the paper guides, then adjust the paper guides to the paper width.



4. Press down the center of the printer cover to close the cover, then tear off the excess paper.




## Loading External Paper Roll




## Preparing for Label Printing

The movable paper sensor must be fixed as shown below to make sure that paper sensor can detect the paper status and label location under label printing mode.



## Connecting Power

1. Make sure the printer is "Off".
2. Connect the AC adapter with power interface.
3. Connect the AC adapter with power cord.
4. Plug the other side of power cord into the socket outlet.



Varies by local or region

**Note:** Windows Driver Installation please see *LPQ58+80 User Manual*.