


Quick Start Guide

TP585-i




Xiamen Hanin Electronic Technology Co., Ltd.

ADD: 5F, 8# Building, Aide Airport Industrial Park, Huli District, Xiamen, China


WEB: www.hpert.com

Appearance and Components


■ Rear




■ Inside




■ Front



Packing List



Printer




Power Cord



Quick Start Guide



Paper Roll




Power Adapter

⚠ Notes:


- 1) The accessories depend on orders.
- 2) The power adapter and power cord vary by region.

Paper Loading (front output direction)

1. Pull the cover-opening lever to open the front cover, as shown in the following figure. If there is a core of paper roll in printer, please take it out.



2. Put the paper roll into the printer, and pay attention to the correct direction of the paper roll.




Thermosensitive surface




Paper Loading (front output direction)

3. Pull out a small amount of paper from the front of the paper roll and close the front cover



4. Tear the excess paper.



Bluetooth/Ethernet/Wi-Fi Settings

1. BT setting

Default name: TP585i_BT

Default password: 0000 or 1234

Please refer to the Bluetooth Manual of the printer. (scan the QR code below for details)



Note: this setting is only available to devices with Bluetooth function

2. Ethernet setting

Connect the printer to Ethernet; the default Ethernet mode is DHCP mode; please refer to the User Manual for details.

Note: this setting is only available to devices with Ethernet function

3. Wi-Fi Setting

Printer WiFi factory default is AP mode with IP address "192.168.100.1" and SSID "TP585i_AP-XXXX". After the PC or mobile phone is connected to printer successfully, users can click below link and do some parameter settings.

Link: <http://192.168.100.1/>

User Name: set by the user at the first time login.

Password: the initial password is empty, which is set by the user.

You need to enter a user name and password only if you click on the link above.



Note: this setting is only available to devices with Wi-Fi function

Power Connecting

1. Connect the power adapter to the printer.
2. Connect the power cord to the power adapter.
3. Connect the power cord to the sockets.
4. Press and hold the power button for 3s to start up.

