


# HPRT

## Quick Start Guide SL41




**Xiamen Hanin Electronic Technology Co.,Ltd.**

ADD: 5F, 8#, Aide Airport Industrial Park, Huli District, Xiamen, China


TEL: 0592-5885991

WEB: [www.hpert.com](http://www.hpert.com)


### Packing List



Printer



AC Adapter



Power Cord



USB Cable



Quick Start Guide




CD


**⚠ Note: The packing materials are actually based on the order.**

### Appearance and Components

#### ■ Front View




#### ■ Rear View




**⚠ Note: The views above are for your reference. Ports vary by your choice.**

## ■ Inside View





5. Pull some paper and pass it through paper guides, adjust paper guides according to the paper width.
6. Press down the top cover until it closes.




## Loading the Roll

1. Press the left and right cover open lever with hands simultaneously and lift the printer cover.
2. Hold the paper roll shaft and take it out.




3. Load the paper roll in the shaft.


- 1 Paper roll shaft loading  
1 inches




- 2 Paper roll shaft loading  
1.5 inches




4. Then load the paper module from the top down to printer.



## USB Connection



## Power Connection



1. Make sure the printer is "OFF"
2. Connect the AC adapter to printer.
3. Connect the power cord to AC adapter.
4. Connect the other side of power cord to the socket outlet.

**⚠ Note:** tool and driver installation please refer to SL41 User Manual.