


HPRT

Quick Start Guide

HD100 HD130



Xiamen Hanin Electronic Technology Co.,Ltd


ADD: 5F, 8#, Aide Airport Industrial Park, Huli
District, Xiamen, China 361009

TEL: +86-(0)592-5885993


FAX: +86-(0)592-5885992

WEB: www.hpert.com

Packing List



Printer




AC Adapter



Power Cord



USB Cable



Thermal Label Roll



CD




Quick Start Guide


Note: The packing materials are actually based on the order.

Appearance and Components


■ Front View



■ Rear View




■ Inside View




Note: The views above are for your reference. Ports vary by your choice.

Loading the Roll


1. Press the left and right cover open lever with hands simultaneously and lift the printer cover.




2. Pull the roll holders open and place the roll between them.





3. Make sure the roll paper close to paper roll holders and press down the locking tab.



4. Pass the labels through label guides and adjust label guides to label's width.




5. Press the lock and close the cover slightly. 6. Press down the cover until it closes.



Connecting the Power

1. Make sure the printer's power switch is "OFF".
2. Connect the AC adapter to power receptacle.
3. Connect the power cord to AC adapter.
4. Connect the other end of power cord to the outlet.



⚠ Note: Please refer to windows driver installation in HD100 and HD130 User Manual.